



1. Unscrew Old Adapter



2. Hold New Adapter  
Upside Down and Put NEW  
Spring in Center



3. Screw Together New  
Adapter

